


Eighth St South

Basement Floor

Emergency Evacuation
Assembly Point is the
Top of the Curran Parking
Deck to South




For emergency access contact the duty staff pager at 404-533-7197 or the campus police at 404-894-2500

Eighth St South

1st Floor

Emergency Evacuation
Assembly Point is the
Top of the Curran Parking
Deck to South



PRIMARY
ROUTE



FIRE EXTINGUISHER




FIRE PULL BOX

For emergency access contact the duty staff pager at
404-533-7197 or the campus police at 404-894-2500

Eighth St South

2nd Floor

Emergency Evacuation
Assembly Point is the
Top of the Curran Parking
Deck to South




For emergency access contact the duty staff pager at 404-533-7197 or the campus police at 404-894-2500

Eighth St South

3rd Floor

Emergency Evacuation
Assembly Point is the
Top of the Curran Parking
Deck to South




For emergency access contact the duty staff pager at 404-533-7197 or the campus police at 404-894-2500

Eighth St South

4th Floor

Emergency Evacuation
Assembly Point is the
Top of the Curran Parking
Deck to South



For emergency access contact the duty staff pager at 404-533-7197 or the campus police at 404-894-2500