


Field Hall

Ground Floor

Emergency Evacuation Assembly Point is across
Techwood Dr. at the Alpha Epsilon Pi House




For emergency access
contact the duty staff pager at
404-533-7197 or the Campus
police at 404-894-2500.

Field Hall

First Floor

Emergency Evacuation Assembly Point is across
Techwood Dr. at the Alpha Epsilon Pi House




For emergency access
contact the duty staff pager at
404-533-7197 or the Campus
police at 404-894-2500.

Field Hall

Second Floor

Emergency Evacuation Assembly Point is across
Techwood Dr. at the Alpha Epsilon Pi House




For emergency access
contact the duty staff pager at
404-533-7197 or the Campus
police at 404-894-2500.

Field Hall

Third Floor

Emergency Evacuation Assembly Point is across
Techwood Dr. at the Alpha Epsilon Pi House




FIRE EXTINGUISHER FIRE PULL BOX

For emergency access
contact the duty staff pager at
404-533-7197 or the Campus
police at 404-894-2500.

Field Hall

Fourth Floor

Emergency Evacuation Assembly Point is across
Techwood Dr. at the Alpha Epsilon Pi House



FIRE EXTINGUISHER FIRE PULL BOX

For emergency access
contact the duty staff pager at
404-533-7197 or the Campus
police at 404-894-2500.