


# Matheson Hall

## Basement Floor

Emergency Evacuation Assembly Point  
is Hopkins Courtyard




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Matheson Hall

## First Floor

Emergency Evacuation Assembly Point  
is Hopkins Courtyard




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Matheson Hall

## Second Floor

Emergency Evacuation Assembly Point  
is Hopkins Courtyard




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Matheson Hall

## Third Floor

Emergency Evacuation Assembly Point  
is Hopkins Courtyard




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Matheson Hall

## Fourth Floor

Emergency Evacuation Assembly Point  
is Hopkins Courtyard



For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.