


# Perry Hall

## First Floor

Emergency Evacuation Assembly Point  
is Perry-Matheson Parking Lot




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Perry Hall

## Second Floor

Emergency Evacuation Assembly Point  
is Perry-Matheson Parking Lot




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Perry Hall

## Third Floor

Emergency Evacuation Assembly Point  
is Perry-Matheson Parking Lot




For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.

# Perry Hall

## Fourth Floor

Emergency Evacuation Assembly Point  
is Perry-Matheson Parking Lot



For emergency access  
contact the duty staff pager at  
404-533-7197 or the Campus  
police at 404-894-2500.