


Harrison Hall

Basement Floor

Emergency Evacuation Assembly Point
is the Courtyard by Harris Patio




FIRE EXTINGUISHER FIRE PULL BOX

For emergency access contact the
duty staff pager at 404-533-7197 or
the Campus police at 404-894-2500.

Harrison Hall

First Floor

Emergency Evacuation Assembly Point
is the Courtyard by Harris Patio




For emergency access contact the
duty staff pager at 404-533-7197 or
the Campus police at 404-894-2500.

Harrison Hall

Second Floor

Emergency Evacuation Assembly Point
is the Courtyard by Harris Patio




For emergency access contact the
duty staff pager at 404-533-7197 or
the Campus police at 404-894-2500.

Harrison Hall

Third Floor

Emergency Evacuation Assembly Point
is the Courtyard by Harris Patio



For emergency access contact the
duty staff pager at 404-533-7197 or
the Campus police at 404-894-2500.