

# Tenth and Home Apts. - Bldg D

## First Floor




Emergency Evacuation Assembly Point is at the GLC Courtyard

For emergency access contact the duty staff pager at 404-533-7197 or the Campus police at 404-894-2500.

# Tenth and Home Apts. - Bldg D

## Second Floor




For emergency access contact the duty staff pager at 404-533-7197 or the Campus police at 404-894-2500.



# Tenth and Home Apts. - Bldg D

## Third Floor




For emergency access  
contact the duty staff  
pager at 404-533-7197  
or the Campus police  
at 404-894-2500.



# Tenth and Home Apts. - Bldg D

## Fourth Floor



For emergency access  
contact the duty staff  
pager at 404-533-7197  
or the Campus police  
at 404-894-2500.

