Fulmer Hall
First Floor

Emergency Evacuation Assembly Point is across McMillan St. to front of "Under the Couch"



PRIMARY ROUTE

FIRE EXTINGUISHER

FIRE PULL BOX

For emergency access contact the duty staff pager at 404-533-7197 or the Campus police at 404-894-2500.

Fulmer Hall
Second Floor

Emergency Evacuation Assembly Point is across McMillan St. to front of "Under the Couch"



PRIMARY ROUTE

FIRE EXTINGUISHER

FIRE PULL BOX

For emergency access contact the duty staff pager at 404-533-7197 or the Campus police at 404-894-2500.

Fulmer Hall
Third Floor

Emergency Evacuation Assembly Point is across McMillan St. to front of "Under the Couch"



PRIMARY ROUTE

FIRE EXTINGUISHER

FIRE PULL BOX

For emergency access contact the duty staff pager at 404-533-7197 or the Campus police at 404-894-2500.